



Calibration instructions for OAK cameras with fisheye lenses

1. First, install the DepthAI calibration Python software:

```
# Optional but recommended: create and activate Python virtual environment
python3 -m venv venv && source venv/bin/activate

# Clone DepthAI repository for calibration
git clone https://github.com/luxonis/depthai.git
cd depthai


# Install DepthAI calibration dependencies
python install_requirements.py
```

2. In the depthai folder, create a file called `resources/boards/MY-BOARD.json` with the following contents

```
{
    "board_config": {
        "name": "BW10980BC",
        "revision": "ROM0E0",
        "swap_left_and_right_cameras": true,
        "left_fov_deg": 127.0,
        "rgb_fov_deg": 68.7938,
        "left_to_right_distance_cm": 7.5,
        "left_to_rgb_distance_cm": 3.75
    }
}
```

and check that the [blue](#) items match the specifications of your device.

3. Open [this calibration pattern](#) on your screen (as large as possible)
4. Measure the width of the black squares as demonstrated in the picture below (the square size is **2.827cm** in this example)



5. Connect the OAK device to an USB port
6. Run the calibration script with the correct **square size**.

```
python calibrate.py --squareSizeCm 2.827 -brd my-board -db
```

and follow the on-screen instructions (see examples below). The “calibration error” should be less than 0.5. A dual monitor setup is recommended (or a laptop + one external monitor).

